

Message

---

**From:** Davis, Eva [/O=EXCHANGELABS/OU=EXCHANGE ADMINISTRATIVE GROUP (FYDIBOHF23SPDLT)/CN=RECIPIENTS/CN=D2BB073C80BE4F5482E94FFE2031042B-DAVIS, EVA]  
**Sent:** 11/30/2017 6:21:32 PM  
**To:** Bruce C W McGee [mcgee@mcmillan-mcgee.com]  
**Subject:** RE:  
**Attachments:** naplvol.mem.wpd

Hey Bruce – I never try to calculate mass in the ground, and I'm not aware of a reference to try to calculate it. I have attached a memo written by a couple of my colleagues to calculate the mass of jet fuel in the ground at Williams Air Force Base – it's the best writeup that I know of that details how they calculated mass in the ground. Hope it helps - Eva

---

**From:** Bruce C W McGee [mailto:mcgee@mcmillan-mcgee.com]  
**Sent:** Thursday, November 30, 2017 10:15 AM  
**To:** Davis, Eva <Davis.Eva@epa.gov>  
**Subject:**

Hey Eva

Do you have a reference or a directive that I can use to calculate TCE mass in place based on several soil borings.

Thanks

Bruce

---

**McMillan-McGee** | Bruce C W McGee | [Do the Math - Live in the Solution](#)  
Headquarters | 4895 35B Street SE, Calgary Alberta, T2B 3M9, Canada  
Contact | cell : 1 403.629.5101 | email : [mcgee@mcmillan-mcgee.com](mailto:mcgee@mcmillan-mcgee.com)

---

This email and attachments may contain confidential information intended solely for the addressee(s) as indicated above. If you are not the intended recipient of this document, please notify sender immediately and destroy all copies. Disclosure, reproduction, distribution or any other use is prohibited and unlawful. Thank you. Please consider the environment before printing this email.